

# REPAIR SHOP PRICE GUIDE

**ALL INSTRUMENTS: Minimum Bench Fee: \$20.00**

**\$60.00 per hour** after bench fee based on 15 min. increments

Pricing **DOES NOT** include parts

*RUSH CHARGE of \$20 may be applied if promised sooner than a business week  
ESTIMATES given for work requiring more than 1/2 hour*

## GUITAR, BASS, VIOLIN/VIOLA

Pricing **DOES NOT** include cost of strings

*(not responsible for strings that break during work)*

### RESTRING SET UP

*(includes neck service/intonation)*

Acoustic/Electric	<b>\$40</b>	<b>\$65</b>
Classical	<b>\$50</b>	<b>\$75</b>
Electric Bass	<b>\$55</b>	<b>\$70</b>
Violin/Viola	<b>\$40</b>	

*Electronic repairs: \$25.00 assessment*

## BRASS & WOODWIND

**Minor Repairs: \$20 minimum. End total is time spent plus parts.**

<b>GENERAL SERVICE</b>		<b>REPAD</b>
Flute	<b>\$45</b>	<b>\$150</b>
Clarinet	<b>\$45</b>	<b>\$150</b>
Alto Sax	<b>\$55</b>	<b>\$250</b>
Tenor Sax	<b>\$65</b>	<b>\$300</b>
Trumpet	<b>\$65</b>	
Trombone	<b>\$55</b>	

*Any work above general service, ie; soldering, dent removal, etc is billed @shop rates*

### **Rosehill Music Rentals:**

*Repairs **NOT** due to normal use are billed @shop rate*